## Setting up a software environment for compiling the Winlink IONOS HF/VHF Channel Simulator

There a few step to build the correct Arduino environment to allow you to compile, load and run the IONOS software.

First you need to install a current Arduino system.

Install the IDE for your computer from: https://www.arduino.cc/en/main/software Current version is 1.8.13, we also support 1.8.12

NOTE: If you're on a MAC under OSX Ver  $10.10 \rightarrow 10.15$ , there is a complete package from the Teensy site that will load the Arduino and the Teensyduino files as one operation: https://www.pjrc.com/teensy/td\_download.html

Setup a folder on you desktop (or wherever you want to keep the files...) Let's call it IONSON-Development.

Start Arduino, go to Preferences menu, an set the Sketchbook location to this IONSON folder.

Test this by compiling an example from the Files→Examples menu. Under the Tools Menu, select your Board and I/O Port Open any example, and try to compile it... Save the program in your IONSON folder. Make sure it there, then you can delete it as needed.

If all this is fine, then we can load the Teensy 4.0 files...

Download the Teensy 1.52 files from: https://www.pjrc.com/teensy/td\_download.html

> Follow the detail instruction on installing the files... As above, try a Teensy example, make sure it compiles and that it can you

can save the program in the IONSON folder. Again, delete is needed...

You now have a working copy of the Arduino IDE and Teensy tools, its now called Teensyduino, but we must add the libraries and IONSON code to this environment.

Library items that we need:

Teensy Audio Library. (installed when you loaded the Teensy tools above)

ILI9341\_t3 LCD Drivers from: https://github.com/PaulStoffregen/ILI9341\_t3

Encoder2, this is from the Winlink Github Bounce2, from : https://github.com/thomasfredericks/Bounce-Arduino-Wiring/archive/master.zip

When you get done, your folders should look like this:

## IONSON-Development folder

| | IONSON-xxx | IONSON-xxx.ino ← the main program |Library | Encoder2 | ILI9341+t3 | Bounce2

To compile and run the code, connect the IONSON via a USB cable to your computer.

Start Teensyduino program.

Under Tools → Boards, select the Teensy 4.0 Under Tools → Port:, select the Serial/USB port Under Files →Open, select the IONSON-xxx.ino program Under Tools → Optimize, select: Debug Under Tools → Select: Serial Monitor

Try a compile, if all is working well, you should see a line something like this at the end:

"Sketch uses 147696 bytes (7%) of program storage space. Maximum is 2031616 bytes.

Global variables use 193204 bytes (36%) of dynamic memory, leaving 331084 bytes for local variables. Maximum is 524288 bytes."

If all is working, try to compile and download to the hardware...